

# ***Technical* Bulletin**

Bulletin No: TB 1008      Effective Date: 4/26/12      Issued By: Brian Willingham      Page: 1 of 1

Subject: Zappi Controller 11980227

Zappi recently has locked out their parameters, there is a certain method to unlocking these parameters, please follow the steps below:

1. Go to the menu ALARMS
2. Press Enter
3. Press the upper right and lower right buttons at the same time
4. Scroll the menus until you find the menu SPECIAL ADJUSTMENT, then press enter
5. Search the option "PARAM. CHANGE EN" and set it to ON
6. Now you can change the parameters in the new H3